

MASSAGE CUSHION


Product manual





Thank you for choosing our products!
Please read tism anual carefully before use and keep it for fuure reference.


/ Schematic diagram of manual controller



Foot controller



Neck massage pillow controller



Mattress controller

/Usage method

Dear client:

Thank you very much for purchasing this product, it has been strictly tested and proved to be safe and reliable. Please read this manual carefully before use, so that you can master the correct way of using it, Please pay attention to important safety warnings when reading especially, and keep this manual properly for reference.

How to use the foot controller:

1. ON/OFF Key: press the ON/OFF Key to enter automatic massage. The default timing is 15 minutes (automatic switching between positive and negative).
2. Direction key: press the direction key to change the massage direction of the massage head. Press once for forward massage, and then press once for reverse massage.
3. Strength key: press this key for the first time after starting up to switch to strong gear, and then press it again to switch. There are three gears to choose from.
4. Heating key: press the heating key to select warm massage. Press once for warm start, and then press once for warm close.

Instructions for neck controller:


ON/OFF Key: Press once to switch on the heating and massage modes
Press twice to heat up and reverse the massage head.
Press three times Massage mode only
Press four times to switch off

Instructions for mattress controller:

1. ON/OFF Key: Press to power on and enter auto mode with a default 10-minute timer. Press again to power off.
2. Shoulder Vibration: Press to exit auto mode and activate shoulder vibration, displaying " P1"
3. Back Vibration: Press to exit auto mode and activate back vibration, displaying "P2"
4. Hip Vibration: Press to exit auto mode and activate hip vibration, displaying "P3"
5. Leg Vibration: Press to exit auto mode and activate leg vibration, displaying "P4".
6. Mode Button: Press to select fullbody vibration with 9 different modes, displaying "F1"_"F8"_"AU"
7. Timer: Press to adjust the timer, displaying "10-20-30"
8. Intensity Adjustment: Press to increase or decrease vibration intensity with 9 levels, displaying "S1"_"S9"
9. Heating Button: Press to activate heating with 3 levels, displaying "H1"."H3".
   Press until "HO" to turn off heating.

/ Storage

Foldable design, with the use of storage does not take up space.



1. turn the mattress upside down and fold it about one-fifth of the way along the bottom of the mattress

2. Fold again along the bottom

3. Fold the pillow toward the mattress

/ Simple fault analysis and treatment

Common faults	Possible causes	Processing method
The whole machine does not work at all	Power failure or not Whether the adapter is plugged into the power socket Whether the ON/OFF Key is on; Whether the adapter DC plug is connected with the massage mattress DC socket	Use after calling Correctly and firmly insert the adapter into the AC power socket; Turn on the ON/OFF Key; Firmly plug the DC plug and DC socket into each other.
Noise	Whether it is placed correctly	Adjust the position
Over intensity	Mains voltage too low	Use voltage regulator

/ Product parameters

Product name	MASSAGE CUSHION	Rated voltage	12V ⎓
Rated power	36W	Working time	30min