


CARB-20AK-LQ



Ax1



Bx1



Cx1



Dx3



Ex1



Fx1



Gx1



Hx3



Ix6
M6x35



Jx20
M6x16



Kx20



Lx1



Mx20

SPARE(Ersatzteile)



Ix1
M6x35



Jx1
M6x16




Kx1



Mx1


Schritt 1 (SCHRITT1)

J		4
K		4
M		4




Step2 (SCHRITT2)

J		6
K		6
M		6




Step3 (SCHRITT3)

I		3
---	--	---




Step4 (SCHRITT4)




Step1 (SCHRITT1)

J		4
K		4
M		4




Step2 (SCHRITT2)

J		6
K		6
M		6



Step3 (SCHRITT3)

I		3
---	---	---



Step4 (SCHRITT4)

