




























HK-DE3020

ASSEMBLY INSTRUCTION


Ax2 	Bx1 	1  Wait 72 hours for rebound	3  x2	5 	7 	9 
Cx1 	Dx2 					
Ex2 	Fx2 					
Gx2 	Hx2 	2  x2	4 	6 	8 	
Ix4 	Jx4 					
Kx2 	Lx2 					

HK-DE3020

INSTRUCCIONES DE MONTAJE


Ax2 	Bx1 
Cx1 	Dx2 
Ex2 	Fx2 
Gx2 	Hx2 
Ix4 	Jx4 
Kx2 	Lx2 

1




Espera 72 horas para el rebote

2



x2


3




x2

Inserte las partes (G) y (H) en la posición marcada.


4




5



6




7




K

8

















9



HK-DE3020

ISTRUZIONI DI MONTAGGIO

Ax2 	Bx1 	1  Strappalo da qui Attendi 72 ore per il rimbalzo	3  Gx2 x2 Hx2 Inserire le parti (G) e (H) nella posizione contrassegnata.	5  D H F	7  B C K K	9  A A
Cx1 	Dx2 	2  Ex2 x2 Fx2 I J Press	4  Gx2 Hx2	6  L D	8  E G E G	

















HK-DE3020

Montageanleitung

Ax2 	Bx1 	1 Warten Sie 72 Stunden auf den Rückprall	3 Gx2 Hx2 x2 Setzen Sie die Teile (G) und (H) an die markierte Position ein.	5 	7 B C K 	9
Cx1 	Dx2 					
Ex2 	Fx2 					
Gx2 	Hx2 					
Ix4 	Jx4 					
Kx2 	Lx2 					
2 x2		4 	6 	8 		




















HK-DE3020

INSTRUCTIONS D'ASSEMBLEMENT

Ax2 	Bx1 	1  Déchirez-le ici Attendez 72 heures pour le rebond	3  Gx2 x2 Hx2 Insérez les pièces (G) et (H) dans la position marquée.	5  D F H	7  B C K	9  A A					
Cx1 	Dx2 						2  Ex2 x2 Fx2 I J Press	4  Gx2 Hx2	6  L D	8  E G	
Ex2 	Fx2 										
Gx2 	Hx2 										














HK-DE3020

MONTABELINSTRUCTIE

Ax2 	Bx1 	1  Haal het van hier af	3  x2 Gx2 Hx2	5  D H F	7  B C K	9  A A
Cx1 	Dx2 	 Wacht 72 uur voor rebound	4  Gx2 Hx2	6  L D	8  E G E G	
Ex2 	Fx2 	2  Ex2 Fx2 J J I I Press				
Gx2 	Hx2 					
Ix4 	Jx4 					
Kx2 	Lx2 					

INSTRUKCJA MONTAŻU

HK-DE3020

Ax2 	Bx1 	1  Rozewijstad Poczekaj 72 godziny na odbicie	3  Gx2 x2 Hx2 Włóż części (G) i (H) do zaznaczonej pozycji.	5  D F H	7  B C K K	9  A A
Cx1 	Dx2 	2  Ex2 x2 Fx2 I J Press	4  Gx2 Hx2	6  L D	8  E G E G	